SILVER CLEANER

CHRISTOFLE FLASHARGENT

A silver dip with a basket. Keep silverware looking fresh and bright with a quick bath in Christofle's Flashargent cleaning solution. Helps remove tarnish and restore original shine even from irregular surfaces. pH 1.5

APPLICATIONS

Flatware, jewellery and decorative items.

EQUIPMENT

- Lint-free cloths
- Gloves to protect your hands



Product ISICH030 Size 500ml

INSTRUCTIONS

Step 1

• Dip pieces in this highly concentrated liquid for just a few seconds (3 is enough) and traces of tarnish will disappear

N.B. For best results, it is recommended to use this product after polishing

Step 2

- Rinse item thoroughly and carefully under warm running water
- Dry well immediately with a soft absorbent cloth
- Do not allow stainless steel knife blades come into contact with Flashargent
- When cleaning jewellery ensure that any steel or stone parts do not come in contact with the liquid

TIPS

- For extremely tarnished silver (almost black in colour) it is recommended to dip it first in Flashargent, which will loosen the oxidisation, then polish with Christofle's Antitarnish Paste and then dip again
- This product is highly toxicuse with caution

to order

Shop online www.eyservices.com Call +33 (0)4 89 02 43 40 Email info@eyservices.com Whilst every effort has been made to ensure the accuracy of the information supplied herein, Earthly Supply Company cannot be held responsible or liable for any damage or injury arising from the use or misuse of these products.