

Sorella Rinse Aid is a clear liquid that gives shine to your dishes and keeps the dishwasher scale-free. It helps to prevent the formation of water stains on glasses, crockery and cutlery and accelerates the drying process. Contains citric acid. Fragrance free. Biodegradable. pH 2-3

APPLICATIONS

Dishware, silverware, stainless steel and glassware

 Sorella Rinse Aid is reserved exclusively for use in dishwashers



<i>Product</i>	PDWHA02
<i>Size</i>	1 L

DIRECTIONS

- Fill the rinse aid reservoir of your dishwasher with Sorella Rinse Aid.
- The dosage is automatic according to the adjustment on the machine.

TIPS

- To de-scale and deodorize the dishwasher: Pour 150ml of rinse aid into the machine then run on an empty cycle at 60°C.
- For best results use in combination with Sorella Dishwasher Powder and Regenerating Salt.

TO ORDER

Shop online www.eyservices.com

Call +33 (0)4 89 02 43 40

Email info@eyservices.com

Whilst every effort has been made to ensure the accuracy of the information supplied herein, Earthly Supply Company cannot be held responsible or liable for any damage or injury arising from the use or misuse of these products.