

Ecological limescale remover for professional use. Use this product for the periodic, thorough removal of limescale deposits and general cleaning of kitchen appliances, dishwashers, coffee machines, etc. Rapid action. Low foam formation. Free from chlorine compounds, petroleum-based surfactants and inorganic acids. pH 2

#### APPLICATIONS

Decalcification of kitchen appliances, dishwashers, coffee machines, etc.

⚠ Not recommended for use with chrome-plated or nickel-plated parts



*Product* PMCGR010  
*Size* 5L

#### INSTRUCTIONS

- Prepare a 5% solution of Crystal Calc in hot water and allow it to circulate for 30 minutes (one full cycle in a coffee machine)
- Allow the machine to drain then rinse it with warm water
- Start a new cycle with dishwasher liquid or powder and allow the mixture to circulate until all the acid residues have been neutralised

#### TIPS

- Crystal Calc can be applied undiluted to a sponge and used to remove limescale deposits and grime from rubber gaskets

#### TO ORDER

*Shop online* [www.eyservices.com](http://www.eyservices.com)

*Call* +33 (0)4 89 02 43 40

*Email* [info@eyservices.com](mailto:info@eyservices.com)

Whilst every effort has been made to ensure the accuracy of the information supplied herein, Earthly Supply Company cannot be held responsible or liable for any damage or injury arising from the use or misuse of these products.